



It's all about the fish®











Important advice that will make your aquarium experience simple and successful.



Success Tip 2 Feeding Give your fish one small pinch of food 2 or 3 times per day. Success Tip 3 Water Changes Only change 25% of the water Once per month. Never empty all the water at once.

Water Change

AQUEON

Making Success Simple Drip Loop


Whenever you plug in any electrical appliance, it's important to utilize a "drip loop". This prevents water droplets from reaching the electrical outlet, which can cause a severe hazard.

To make a drip loop, follow the diagram to the right. Simply drop the power supply cord below the level of the outlet you're plugging it into. This way, if any water should get on the cord, it will drip off before it reaches the electrical outlet.



It's all about the fish®

1. place aquarium on **Strong, Stable Surface**





• Surface should be able to easily support more than 80 lbs.



2. add Gravel



Rinse gravel in collander

- Carefully pour rinsed gravel into middle of aquarium.
- Spread gravel evenly around aquarium bottom.
- Gravel depth should measure about 1" - 3" from the bottom.



3. add **Plants, Décor**



Rinse plants and décor items

- Place plants and décor items into aquarium in desired location.
- Cover base of plants and bottom of décor items with gravel to hold securely in place.



4. add Water



Add Water Conditioner as directed

- Pour room-temperature water into aquarium over your hand to avoid moving gravel, plants and décor.
- Fill aquarium with water to 1/2" from top of frame.
- Add water conditioner.



5. add **Filter**



Rinse filter cartridge before use

- Place filter holder on back of aquarium so that clips on back and sides hold firmly in place.
- Place filter in filter holder with filter clip so that filter is held firmly in place.
- Place rinsed filter cartridge into filter making sure that the word "front" on filter cartridge tab is facing up to secure in place.



6 add **Cover** and **MP3 Device**

7. connect MP3 Device and Speakers



Use rocker switch to operate light

- Position filter power cable to run down back wall of aquarium.
- Plug USB connector from light cable into USB bar on bottom back of aquarium.
- Add cover, positioning the feeding hole towards front of aquarium.
- Insert MP3 device into cradle if applicable.





Connect the included 3.5mm audio cable to the MP3 device and "audio in" on the speaker.

- Plug mini USB end of included USB cable into "USB Power" on speaker. Plug opposite, standard size USB end into USB bar on bottom back of the aquarium.
- Plug the hardwired mini USB cable that runs from the speaker into second speaker.



8. connect Cables



Plug charging cable (not included) into MP3 device. Tuck audio and charging cables into channel.

- Plug USB charging cable from MP3 device into USB bar on bottom back of aquarium.
- Connect included transformer male end to female end from USB bar. Plug other end of transfomer into wall socket.
- Plug filter power cable into wall socket. (cords color-coded for reference only)

GREEN - USB from LED light to USB bar ORANGE - USB from MP3 device charger to USB bar YELLOW - 3.5 mm audio from MP3 device to speaker RED - USB from speaker to USB bar BLUE - hardwired USB cable from speaker to speaker PURPLE - from filter to wall



9. add **Fish**



Wait 24 hours before adding fish

- · Remove aquarium cover.
- Place fish, while in bag from store, into aquarium. Let sit for 20 minutes.
- Open bag and add about 1/2 cup of aquarium water. Wait 5 minutes. Repeat once.
- Carefully allow fish to enter aquarium. Replace cover.

